


Measuring the Dimensions of Your Filter Cartridge

****Please check the dimensions of your current cartridge before purchasing****



1) Measure the Outside Diameter of the End Cap. Use exact measurement (+ or - 1/32")

2) Measure Cartridge Length. End cap to end cap (+ or - 1/16"). Exclude any handles or extensions.

3) Top Inside Diameter. Use exact measurement (+ or - 1/32")